

INSTALLATION AND MAINTENANCE



KBP PLATINUM^X BMS



ECO PRO Controller - Optional Accessory For BMS Models

KBP PlatinumX BMS and KBP PlatinumX PRO unit heaters are to be operated at voltage listed on the rating label. It is important to verify the power supply voltage is the same as the nameplate voltage of the heater. Connecting the heater to an improper voltage or failure to follow the procedures as outlined in this manual can result in damage to the heater and void the warranty. Disconnect all power from the heater at the main service panel before attempting to install or service this unit. All electrical wiring must conform to local electrical codes. Heater circuit must be properly protected.



WARNING



READ CAREFULLY - Use the heater only as described in this manual. Any other use is not recommended and could result in fire, electric shock, and personal injury. Following these instructions will prevent difficulties that might occur during the installation and use of the heater. Please study the instructions first, as they may save considerable time and trouble during use addition to providing important safety information. Make

Read all instructions before wiring or using this heater.

- WARNING** Heaters outlet grill is very hot when in use. To avoid burns, do not touch hot surfaces with bare skin. Keep combustible materials, including furniture, pillows, bedding, papers, clothes, curtains, and boxes at least 3 feet from the front of the heater and keep them away from the sides and rear.
- WARNING** Do not use outdoors.
- WARNING** Heater is not intended for use in bathrooms, laundry areas or similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- WARNING** Do not insert or allow foreign objects to enter any inlet or outlet openings as this may cause an electric shock, fire, or damage to the heater.
- WARNING** To prevent a possible of fire, do not block air intakes or exhaust in any manner.
- WARNING** Heater has hot surfaces. Internal thermostat and limiting parts can arc or create sparks inside. Do not use this heater in areas where gasoline, paint, or flammable liquids or gases are used or stored.
- WARNING** Use this heater only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electric shock, explosion or injury to people and or property.
- WARNING** If heater shows signs of overheating immediately turn the circuit breaker off to the heater. Remove and inspect for any objects on or adjacent to the heater that may cause the high temperatures. Have a professional inspect the internals until the reason is clear why the heater is overheating. Do not reinstall until it has been professionally serviced.
- WARNING** Do not operate heater after it malfunctions. Disconnect heater at service panel and have heater inspected by a reputable electrician before reusing. To disconnect heater, turn controls to off position, and turn off power to heater circuit at main electrical panel or operate internal disconnect switch to off if provided.
- WARNING** Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended too.

SAFETY INFORMATION

KBP PlatinumX BMS / PRO Circuit Sizing Chart

1 PHASE CIRCUIT SIZING TABLE					
Watts (Max)	BTUH	Volts	Amps 1 Phase	Wire Size	Circuit Protection
950	3242	277	3.4	#14/2	15A-2P
1900	6485	277	6.9	#14/2	15A-2P
2850	9727	277	10.3	#14/2	15A-2P
3800	12969	277	13.7	#14/2	15A-2P
4750	16212	277	17.1	#10/2	30A-2P
5700	19454	277	20.6	#10/2	30A-2P

3 PHASE CIRCUIT SIZING TABLE					
Watts (Max)	BTUH	Volts	Amps 3 Phase	Wire Size	Circuit Protection
2850	9727	208	7.9	#14/3	15A-3P
		240	6.9		
		480	3.4		
5010	17065	208	13.9	#12/3	20A-3P
5700	19454	240	13.7	#12/3	20A-3P
		480	6.9	#14/3	15A-3P

WARNING: Prior to operating, make sure the circuit breaker is of the configuration and capacity appropriate for the heater.

IMPORTANT: Per the National Electrical Code heating circuits are considered a continuous load and therefore must be de-rated by 20%.

For example, a 20 amp heating circuit can not have more than 16 amps of connected load.

- Minimum installed distance from the heater to the adjoining wall or ceiling surfaces - 5 inches to back wall.
- When clearance to ceiling is 2 inches, Do Not Point Heater At Ceiling.
- Use extreme caution when used near children or people with disabilities.
- Do not use outdoors.
- Not intended for use in bathrooms, laundry areas or other similar wet locations. Never locate heater where it may have contact with water.

- Do not use heater in wet or moist locations.
- Don't place heater against cardboard or low-density fiberboard surfaces.
- Avoid using an extension cord because the extension cord may overheat and cause a risk of fire.
- Use only the electrical power (voltage and frequency) specified on the model plate of the heater.
- Keep all combustible materials away from this heater.


LOUVER ADJUSTMENT TO DIRECT AIRFLOW

The louvers are opened during testing at factory, but may have shifted during shipping. Confirm louvers are rotated less than 45 degrees from horizontal before operation. To adjust the opening angle, grasp the left and right end of louver and twist with two hands to the desired position.

CAUTION: Increasing angle beyond 45° degrees from horizontal may restrict air flow casing over temperature limit to activate & shut off the heater.

Louver Adjustment


Do Not Adjust While
Heater Is Operational



ASSEMBLY INSTRUCTIONS



king




PLATINUM X

Minimum Clearance From Combustibles


Front	18 in.
Top	2 in.
Sides	6 in.
Rear	5 in.
Floor	6 ft.

INSTALLATION INSTRUCTIONS

FOR WALL MOUNT APPLICATIONS



FOR CEILING MOUNT APPLICATIONS



TOOLS NEEDED:

- Screwdriver (Phillips, Square, & Slotted)
- Wire Cutters
- Pliers
- Adjustable Wrench
- Electric Drill

Remove heater & all packaging materials from the box.

HARDWARE NEEDED:

- Adequate gauge & length of wire for your application
- Proper size fuses or breakers to handle amperage
- Proper wire connectors for your application
- Fasteners appropriate size to mount heater



Tip: Remove the hardware kit package from the box packaging.


MOUNTING HEIGHT:

When the air flow of the heater is directed vertically or horizontally, the minimum mounting height is 6 feet in the USA and 8 feet in Canada. Mounting heights depend upon building utilization and heater KW capacity.

LOCATION OF HEATER: The heater should be installed 6 feet above floor and according to minimum clearance chart. The direction of airflow should not be restricted by machinery, beams, etc., and the air flow should run with walls, rather than blowing directly at them. When more than one heater is used in an area, the heaters should be arranged so that the air discharge of each heater supports the air flow of the others to provide best circulation of warm air.

MOUNTING HEATER: Wall stud and ceiling joists are typically wider than our mounting bracket which is 11 inches wide. The heater weighs 14 lbs. and should be mounted onto at least one stud to be properly supported.

Your fasteners penetrating a stud is critical to supporting the weight. A gypsum wall board fastener is not strong enough. If your ideal location has no solid backing, you can fasten with large screw fasteners a 2" x 6" board to ceiling joists or wall studs. Attach with appropriate lag bolts with proper depth for the 14 lbs. Install wing nut fasteners into the outside of the bracket and star washer between the heater and bracket. Be certain bracket bolts are tightened firmly to secure the heater to swivel bracket.



*For additional flexibility, an optional mounting bracket is available for sale separately.


SAVE THESE INSTRUCTIONS

DIMENSIONAL DATA




Dimensional Data

Minimum clearance from combustibles: 18" from front, 2" from top, 6" from sides and 5" from rear. Minimum clearance 6' from floor.
(Optional Disconnect Switch Shown)

PLATINUMTMX



Optional Disconnect Switch



Note: Optional Swivel Mounting Bracket

TEMPERATURE RISE PER WATTAGE CHART							
WATTS	BTUH	CFM	TEMP. RISE	WATTS	BTUH	CFM	TEMP. RISE
950	3,242	385	8	3800	12,969	385	31
1000	3,413	385	8	4000	13,652	385	33
1900	6,485	385	16	4160	14,198	385	34
2000	6,826	385	16	4750	16,212	385	39
2850	9,727	385	23	5700	19,454	385	47
3000	10,239	385	25	6000	20,478	385	49

WIRING INSTRUCTIONS



WARNING Before proceeding further with the installation of this heater, turn off the power and lock the supply line for the heater at the main service box.


WIRING INSTRUCTIONS

1. Remove wiring compartment cover.
2. Remove one of the knock outs from the back of the unit. It is not necessary to remove the grill cover.
3. Size service wire to adequately handle amp load of the heater. Refer to the Circuit Sizing Table for proper wire size and circuit protection.
4. Connect supply wire to L1 & L2 & L3 as applicable as shown in the wiring diagrams provided with heater.
5. Secure power supply cable with cable clamp.
6. Connect ground wire to the ground lug.
7. Adjust the heater to the desired position.

Field-Adjustable Wattages 1 Phase Models

Pic-A-Watt® Heating Element Exclusive King multi-tap element allows field adjustment to several wattages at time of installation. Reference the wiring diagram when adjusting the wattage. The below tables should be used as a supplement to your wiring diagram.

Element End View for Single Phase “-1” Models



Single phase models have a welded busbar connecting all element commons together. This is depicted by “COM” in the diagram above. There is only 1 connection point for the “COM” common connection. This will not be removed when adjusting the wattages.

KBP2005-1MP-MB-PLTMX*		
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION
ELEMENT 1 - 208V - 2850W		
A	YELLOW	720
B	ORANGE	720
C	RED	720
ELEMENT 2 - 240V - 2850W [2250W @ 208V]		
D	YELLOW	950
E	ORANGE	950
F	RED	950

208V - 5010W - 3MP 1-PH

ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES

NONE	5010
F	4060
B & E	3340
B & D & E	2390
B & C & E & F	1670

*THIS IS THE CONVERTED TO 1-PH VERSION OF THIS MULTIPHASE MODEL

KBP2706-1-MB-PLTMX		
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION
ELEMENT 1 - 277V - 2850W		
A	RED	950
B	BLUE	950
C	RED	950
ELEMENT 2 - 277V - 2850W		
D	YELLOW	950
E	ORANGE	950
F	RED	950

277V - 5700W

ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES

ATTENTION: DO NOT REMOVE BLACK E1 COM OR E2 COM WIRES ATTACHED TO BUSBAR ON EACH ELEMENT

NONE	5700
A	4750
A & F	3800
B & D & F	2850
B & D & F	1900

KBP2406-1MP-MB-PLTMX*		
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION
ELEMENT 1 - 240V - 2850W		
A	YELLOW	950
B	ORANGE	950
C	RED	950
ELEMENT 2 - 240V - 2850W		
D	YELLOW	950
E	ORANGE	950
F	RED	950

240V - 5700W - 3MP 1-PH

ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES

NONE	5700
A	4750
A & F	3800
B & D & F	2850
A & C & D & F	1900

*THIS IS THE CONVERTED TO 1-PH VERSION OF THIS MULTIPHASE MODEL

KBP4806-1MP-PLTMX*		
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION
ELEMENT 1 - 480V - 2850W		
A	YELLOW	950
B	ORANGE	950
C	RED	950
ELEMENT 2 - 480V - 2850W		
D	YELLOW	950
E	ORANGE	950
F	RED	950

480V - 5700W - 3MP 1-PH

ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES


*THIS IS THE CONVERTED TO 1-PH VERSION OF THIS MULTIPHASE MODEL

Field-Adjustable Wattages 3-Phase Models

Pic-A-Watt® Heating Element Exclusive King multi-tap element allows field adjustment to several wattages at time of installation.

Reference the wiring diagram when adjusting the wattage. The below tables should be used as a supplement to your wiring diagram.

Element End View for 3 Phase “-3MP” Models



KBP2005-3MP-MB-PLTMX						
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION	208V - 5010W - 3MP 3-PH	ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES	SELECTABLE WATTAGES	
ELEMENT 1 - 208V - 2850W				None	5010	
A	YELLOW	720		A & C & E	2390	
B	ORANGE	720				
C	RED	720				
ELEMENT 2 - 240V - 2850W [2250W @ 208V]						
D	YELLOW	950				
E	ORANGE	950				
F	RED	950				

KBP2406-3MP-MB-PLTMX						
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION	240V - 5700W - 3MP 3-PH	ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES	SELECTABLE WATTAGES	
ELEMENT 1 - 240V - 2850W				None	5700	
A	YELLOW	950		A & C & E	2850	
B	ORANGE	950				
C	RED	950				
ELEMENT 2 - 240V - 2850W						
D	YELLOW	950				
E	ORANGE	950				
F	RED	950				

KBP4806-3MP-PLTMX						
REMOVE ELEMENT POSITION	ELEMENT WIRE COLOR	WATTAGE REDUCTION	480V - 5700W - 3MP 3-PH	ELEMENT LEADS REMOVED TO GET SELECTABLE WATTAGES	SELECTABLE WATTAGES	
ELEMENT 1 - 480V - 2850W				None	5700	
A	YELLOW	950		A & C & E	2850	
B	ORANGE	950				
C	RED	950				
ELEMENT 2 - 480V - 2850W						
D	YELLOW	950				
E	ORANGE	950				
F	RED	950				

OPERATING INSTRUCTIONS

Operation

- Push the  button, the heater will turn on and heat to the default setting of 72°F.
- Once the room temperature reaches the set point, the heat elements will turn off, followed by a 3 minute fan delay period to exhaust excess heat from the case. Afterwards the unit will turn off.
- In normal operation the display will show the current room temperature.

Room Temperature Selection

- During operation, push  or  arrow buttons to set the temperature from 40°F-95°F. Hold down the UP or DOWN arrow to speed up the selection process. The LCD will go back to display room temperature after 5 seconds.

Timer Mode Selection


- During operation, press the  button 1 time, the display window will show the timer mode setup. Push  or  to set Timer from 1 hour—9 hours.

Fan Only Mode Selection

- During operation, press the  button 2 times, the display window will show [H] Heat Mode or [F] Fan Only Mode.


Push  or  to switch between Fan Only and Heat modes.

PlatinumX BMS / PRO Control Panel




PLATINUMX

DISPLAY DIP SWITCH SETTINGS



BMS Model Defaults



PRO Model Defaults

DIP SWITCH 1

OFF = EXTERNAL SENSOR or ECO PRO CONTROLLER (102806 or ECO-PRO-CONTROLLER)
ON = LOCAL SENSOR CONTROL (BMS DEFAULT)

DIP SWITCH 2

OFF = 24V REMOTE STAT (CUSTOMER PROVIDED)

ON = LOCAL STAT (CONTROL SETTING BY DISPLAY) (BMS DEFAULT)

DIP SWITCH 3

OFF = WIRED DOOR/WINDOW/PIR SENSOR CONNECTED

ON with A+B JUMPER INSTALLED = BMS LOCKOUT DISABLED (BMS DEFAULT)

ON with A+B JUMPER REMOVED = BMS LOCKOUT ACTIVE

DIP SWITCH 4

OFF = PIR OCCUPANCY SENSOR

ON = WINDOW/DOOR SENSOR (BMS DEFAULT)

OPERATING INSTRUCTIONS CONTINUED

Display Lock Feature

Display Lock is designed for high traffic areas and deactivates the heater display buttons to prevent unwanted temperature adjustments. However settings can still be adjusted through the remote control.

- During operation, press the  button and HOLD for 5 seconds to set the display lock. [L] will appear on the display temporarily if a user attempts to make a temperature adjustment. While in Display Lock, heater can be adjusted using remote control.

Setting "Environment" Mode

Two Environment Options: Standard [**ST**] and Bedroom [**BE**].

Bedroom Mode turns off the display after 30 seconds for people using this heater in a light sensitive environment. Once any button is pressed the display turns back on.

- During operation, press the  and  buttons for 3 seconds. Then press  or  to select Standard Mode [**ST**] or Bedroom Mode [**BE**]

Factory Reset

- During operation, press and HOLD the  button for 5 seconds to reset to the factory settings. [**FA**] will flash on the display.

Sensor Error Code


- During operation, if the display shows [**E1**] that indicates an issue with the sensor and the sensor needs to be replaced. Contact customer support for assistance.

Setting Differential Value


The differential or gap affects how often the heater cycles. The lower the differential setting, the more the heater will cycle. If heater cycles too often, raise the differential setting to a higher degree.

- Press the  and  buttons for 5 seconds. The display will show the previously set differential. Press  or  to adjust the differential value between -0 to -5.


PlatinumX BMS / PRO Control Panel



DISPLAY DIP SWITCH SETTINGS



BMS Model Defaults



PRO Model Defaults

DIP SWITCH 1

OFF = EXTERNAL SENSOR or ECO PRO CONTROLLER (102806 or ECO-PRO-CONTROLLER)
ON = LOCAL SENSOR CONTROL (BMS DEFAULT)

DIP SWITCH 2

OFF = 24V REMOTE STAT (CUSTOMER PROVIDED)

ON = LOCAL STAT (CONTROL SETTING BY DISPLAY) (BMS DEFAULT)

DIP SWITCH 3

OFF = WIRED DOOR/WINDOW/PIR SENSOR CONNECTED

ON with A+B JUMPER INSTALLED = BMS LOCKOUT DISABLED (BMS DEFAULT)

ON with A+B JUMPER REMOVED = BMS LOCKOUT ACTIVE

DIP SWITCH 4

OFF = PIR OCCUPANCY SENSOR

ON = WINDOW/DOOR SENSOR (BMS DEFAULT)

— SAVE THESE INSTRUCTIONS —

BMS LOCKOUT CIRCUIT (OPTIONAL)

KBP PlatinumX BMS and PRO models features onboard terminals (Figure A) that allow connection to a Building Management System (BMS) to disconnect the heat output remotely when the A/C system is running.

When BMS takes control, heater functions will not work, the touch screen is locked, [BL] light appears on the heater display.

When BMS releases control, heater functions are available, heater resumes operating at previously programmed settings.

Refer to BMS system's Operations Manual for programming options and details.

See below for additional info.



NOTE: DO NOT REMOVE RED JUMPER UNLESS BMS SYSTEM CONTROL IS BEING USED.


CONNECTING A BUILDING MANAGEMENT SYSTEM (BMS) TO DISCONNECT HEATER OUTPUT REMOTELY

Step 1: Wire Building Management System (BMS) To Heater

To utilize the BMS Lockout capabilities remove the red jumper wire between terminals A and B on the control terminal board. (See Figure A). Connect two wires from a dry contact (no voltage) of the BMS system to terminals A and B.

NOTE: DO NOT REMOVE THE RED JUMPER UNLESS CONTROL BY A BUILDING MANAGEMENT SYSTEM IS BEING USED.


Step 2: Dip Switch Selection: On back of the Control Display, switch Dip Switch #3 to ON Position to activate BMS Lockout capabilities.



When BMS contacts are open, System is OFF regardless of room temp.

Control Display shows [BL]

Heater Display – Heater Locked Out




WIRED AUXILIARY CONTROL OPTIONS (OPTIONAL)

KBP PlatinumX BMS and PRO models features onboard terminals (Figure A) that allow a wired auxiliary window/door sensor or PIR Occupancy Sensor for automatic triggering of a setback or off state when the contacts open.



FIGURE A



CONNECTING A WIRED WINDOW/DOOR SENSOR or OCCUPANCY SENSOR TO THE SYSTEM

Step 1: Wire Sensor To Heater


To utilize the Window/Door or PIR Occupancy Sensor capabilities remove the red jumper wire between terminals A and B on the control terminal board. (See Figure A). Connect two wires from a dry contact (no voltage) of the PIR motion sensor or door sensor to terminals A and B.

Step 2:

Dip Switch Selection (Window/Door Sensor):

Switch Dip Switch #3 to OFF position to activate Window/Door or PIR Occupancy capabilities.

Switch Dip Switch #4 to ON position to select Window/Door Sensor




BMS Models Settings - Window/Door Sensor

Dip Switch Selection (PIR Occupancy Sensor):

Switch Dip Switch #3 to OFF Position to activate Window/Door or PIR Occupancy capabilities.

Switch Dip Switch #4 to OFF position to select PIR Occupancy Sensor.



BMS Models Settings - PIR Occupancy Sensor

Step 3: Select Environment Mode Option

When paired with an optional Window/Door or PIR Occupancy sensor there are two environmental modes to choose from when the sensor contacts open: Freeze Protection [FP] and OFF [OF].

Press the and HOLD the **MODE** and **▲** buttons on the Control Display for 3 seconds.

Then Press **▲** or **▼** to select Freeze Protection or OFF mode.

BMS Models Settings

Freeze Protection Mode:


When contact is open, heater sets back the set temp to 40F.

Control Display shows "FP".

OFF Mode:

When contact is open, System is OFF regardless of room temp.

Control Display shows "OF" Pro Controller display shows "OFF".



CONNECTION OF OPTIONAL 24V REMOTE THERMOSTAT

Controlling PlatinumX BMS with a Remote 24V Thermostat

KB PlatinumX BMS heaters come standard with the provisions to connect any 24V remote wall thermostat, for remote temperature sensing and control. Provides silent operation control for use with a 24 Volt Thermostat. Follow steps below for setup and to select Single Stage or Two Stage Control.

Step 1:


Dip Switch Selection On Display For Remote Thermostat—

Local or Remote Thermostat (Figure 1)

The #2 dip switch on the back of the display is used for selecting between the onboard thermostat control and the optional remote wall thermostat control.

Set dip switch 2 to the OFF position to switch to 24V Remote Thermostat Control


24V Remote Thermostat



Dip switch #2:
Off = Remote 24V Thermostat Control

(BMS Models Settings Shown)

Local Thermostat (Default)



Dip switch #2:
On = Local Thermostat Control (default)

Step 2:

Dip Switch Selection On Controller PCB—1-Stage or 2-Stage Thermostat (Figure 2)

Refer to the thermostat operating instructions to determine if the thermostat is a single stage or two stage thermostat.

Select the dip switch setting required.

For 2-Stage Heating > Dip Switch = OFF

For 1-Stage Heating > Dip Switch = ON

Step 3:

Wiring 24V Remote Thermostat to KB Platinum (Figure 3)

Following thermostat manufacturer's instructions.

Figure 1: Back of Display



(BMS Models factory default shown)

Figure 2: Controller PCB



Figure 3: Wiring Schematic Overview

① DISPLAY (107774)

DIP SWITCH 1

OFF = EXTERNAL SENSOR or ECO PRO CONTROL (102806 or ECO-PRO-CONTROLLER)

ON = LOCAL SENSOR CONTROL (DEFAULT)

DIP SWITCH 2

OFF = REMOTE STAT (CUSTOMER PROVIDED)

ON = LOCAL STAT (CONTROL SETTING BY DISPLAY) (DEFAULT)

CONTROL BOARD (107773)

DIP SWITCH 3

OFF = WIRED DOOR/WINDOW/PIR SENSOR CONNECTED

② ON with A+B JUMPER INSTALLED = BMS LOCKOUT DISABLED (DEFAULT)


ON with A+B JUMPER REMOVED = BMS LOCKOUT ACTIVE

DIP SWITCH 4

OFF = PIR OCCUPANCY SENSOR

ON = WINDOW/DOOR SENSOR (DEFAULT)


OPTIONAL 24V REMOTE THERMOSTAT (FIELD INSTALLED)



③ DIP SWITCH SW1

ON = SINGLE STAGE REMOTE STAT (DEFAULT)

OFF = TWO STAGE REMOTE STAT




— SAVE THESE INSTRUCTIONS —

CONNECTION OF OPTIONAL NEST LEARNING THERMOSTAT



Nest King PlatinumX
G ----- G, FAN ONLY

Conventional 1 Stage Heating **PLATINUMX**



NOTES:

- Y1,Y2,OB,RC, & (*) are for Heat Pumps and Air Conditioning, NOT USED on KING HEATERS. The C wire keeps the Nest battery power charged.


CONNECTION OF OPTIONAL NEST BASIC / E THERMOSTAT



To connect a Nest / Nest E Series to PlatinumX, you will need to run multi-conductor thermostat wire between the Nest Learning Thermostat and the PlatinumX terminal board per the wiring diagram below. Thermostat wire is a class 2 power-limited circuit cable for use in thermostat control applications.

Nest King PlatinumX
G ----- G, FAN ONLY
W1 ----- W1, STAGE 1 HEAT
R ----- R, POWER (24VAC)
C ----- C, COMMON

Conventional 1 Stage Heating **PLATINUMX**



SAVE THESE INSTRUCTIONS

CONNECTION OF OPTIONAL ECOBEE THERMOSTAT




To connect a Ecobee to PlatinumX, you will need to run multi-conductor thermostat wire between Ecobee Thermostat and the PlatinumX terminal board per the wiring diagram below. Thermostat wire is a class 2 power-limited circuit cable for use in thermostat control applications.

Conventional 1 Stage Heating

PLATINUMX

Ecobee King PlatinumX

G ----- G, FAN ONLY
W1 ----- W1, STAGE 1 HEAT
RC ----- R, POWER (24VAC)
C ----- C, COMMON



CONNECTION OF OPTIONAL HONEYWELL THERMOSTAT



Model: RTH9585WF1004


To connect a Honeywell model RTH9585WF1004 to PlatinumX, you will need to run multi-conductor thermostat wire between the Honeywell Thermostat and the PlatinumX terminal board per the wiring diagram below. Thermostat wire is a class 2 power-limited circuit cable for use in thermostat control applications.

Conventional 1 Stage Heating

PLATINUMX

Honeywell King PlatinumX

G ----- G, FAN ONLY
W-O/B ----- W1, STAGE 1 HEAT
R ----- R, POWER (24VAC)
C ----- C, COMMON



SAVE THESE INSTRUCTIONS

TROUBLESHOOTING ERROR CODES

Display Code	Display Symbols	Type	Description of Code	Action (if Any)
LS	LS	ERROR	Low Sensor Signal	1. Check and verify Dip Switch settings are correct on the back of the display - refer to instruction manual for settings. 2. Move Sensor closer to the heater or away from metal objects that might block the signal.
BA	BA	ERROR	Low Battery Indicator	Indicate batteries should be replaced.
E1	E1	ERROR	Onboard Sensor Error	Indicates an issue with the backup sensor inside the heater and the sensor needs to be replaced. Contact customer support for assistance.
L	L	FEATURE	Display Lock Mode	Press and HOLD Start/Stop button for 5 seconds to turn off Display Lock
BL	BL	OPTIONAL FEATURE	BUILDING MANAGEMENT SYSTEM - SYSTEM LOCKED	Displays when BMS System Contacts are OPEN
OF	OF	OPTIONAL FEATURE	WINDOW/DOOR/PROXIMITY - SYSTEM OFF	Displays when Window/Door/Proximity Sensor Contacts are OPEN
FP	FP	OPTIONAL FEATURE	WINDOW/DOOR/PROXIMITY - FREEZE PROTECTION MODE (40F SETBACK)	Displays when Window/Door/Proximity Sensor Contacts are OPEN

SMART LIMIT PROTECTION AND MAINTENANCE

Heater Safety Limit Tripped?



This heater is equipped with a thermal overload Smart Limit Protection which disconnects elements and motor in the event normal operating temperatures are exceeded. If thermal overload trips due to abnormal operating temperatures, thermal overload shall remain open until manually reset by turning the heater OFF for fifteen minutes. Inspect for any objects on or adjacent to the heater that may cause high temperatures. After inspecting the heater, keep the power to the heater off for 15 minutes to reset the SLP thermal protector. If the SLP thermal protector shuts the heater off again, immediately turn the heater OFF at the circuit breaker and inspect the heater for possible fan motor failure or dirt and lint on the heating element. Repeat the starting procedure.

DO NOT TAMPER OR REMOVE THIS DEVICE

Maintenance

With proper care your electric heater should last a lifetime, however, seasonal cleaning is recommended to maintain the efficiency of the heater. Keep heating element, fan and motor free of debris. Use compressed air to blow out any debris.

We're Here to Help!

For any difficulties installing or operating this product

Call Us Toll Free at:

1-800-603-5464

7:00 am -3:30 pm PST Mon-Fri

Visit king-electric.com

or email us at info@king-electric.com

SAVE THESE INSTRUCTIONS

ECO PRO CONTROLLER INSTRUCTIONS

KBP PlatinumX PRO models include the ECO PRO Controller, which is a Remote Thermostat, featuring a 7-day programmable heating schedule that puts personalized comfort right at your fingertips. This advanced scheduling function allows users to set different heating profiles for each day of the week, aligning comfort with daily routines while optimizing energy efficiency.

KBP PlatinumX BMS models can be upgraded by purchasing an optional ECO PRO Controller accessory.

Meet the ECO PRO CONTROLLER: 7-Day Programmable Thermostat with Remote Temperature Sensing



7-Day Programmable Heating Schedule



Balanced Heat Throughout the Space



Comfort, Right Where You Want It



Remote Temperature Sensing

PAIRING ECO PRO CONTROLLER TO HEATER


KBP PlatinumX PRO Models Only




IMPORTANT: The ECO PRO Controller must be paired to the heater prior to use. If heater display shows "L5" the ECO PRO Controller has not been paired successfully. Repeat Pairing Process.

HEATER DIP SWITCH SETTINGS

Note: Dip Switch #1 must be set to OFF for ECO PRO Controller



PRO Models Settings



PAIRING AND USAGE GUIDE

Since it is possible that more than one heater/PRO Controller would be used in a home, you must first pair the PRO Controller to a specific heater. Each PRO Controller has a unique ID number, which will be used in the pairing process. When installing the PRO Controller first time, users need to pair the PRO Controller with heater, so the heater can learn and save the remote sensor's ID.

Step 1: On the Heater's Display Press and button at the same time for 5 seconds. The LED display will flash "id". Release buttons.


Step 2: Put the PRO Controller within 3 feet of the heater and then press and hold the button to enter pairing mode.

Step 3: The icon will appear on the PRO Controller, and the heater's display indicator lights will illuminate (LED tubes show 88) for 1 second and then turn off. This means the Pro Controller and the heater have paired with each other successfully.

NOTE: If the display flashes "id" for 20 seconds and then turns off, it means that the heater failed to pair with the PRO Controller and has exited the Pair mode. Repeat the above steps to pair the remote sensor.

Step 4: After pairing the PRO Controller successfully, put the PRO Controller in the room where you want to detect temperature. The heater display will now display the temperature from the remote sensor.

Installing Batteries / Optional USB-C Adaptor



Installing Batteries / Optional USB-C Adaptor

Open the battery cover and insert 3pcs AAA batteries.

Important Note: To conserve battery life the PRO Controller perform a handshake with the heater every 3 minutes. Users may experience up to a 3-minute delay.

Recommendation: For instant communication, a standard USB-C cable and power adapter are recommended to provide constant power.

Low Battery Indicator


Low Battery Indicator

When batteries are low, "BA" will flash on the heater display and  icon appears on the Pro Controller to indicate batteries should be replaced.

Note: If batteries fail, the heater is designed to revert back to the onboard temperature sensor for temperature control until the batteries are replaced in the remote sensor.



Wall Mounting Instructions



Wall Mounting The PRO Controller

PRO Controller can be placed on any flat surface or can be fixed to the wall with the mounting bracket. **Mounting Bracket Install:** Select location for the PRO Controller on the wall,. Secure the bracket to with 2 appropriate anchors and screws. Insert PRO Controller into bracket.

Low Signal Indicator

Low Signal Indicator

When the PRO Controller is not paired with the heater or if the signal is being blocked, the display flashes "LS". After 10 minutes, the controller will automatically switch to work with the on-board temperature sensor, but the display will continue to flash "LS" until the signal restored.

1. Following Pairing process above to successfully pair the sensor.
2. Move PRO Controller closer to the heater or away from metal objects that might block the signal.

INITIAL SETUP OF ECO PRO CONTROLLER


INITIAL SETUP:

Press and hold  and  buttons for 5 seconds to enter SETTINGS steps:

Setting#1: Set °Celsius or °Fahrenheit

Press  or  to select °C or °F (Default °F).

Press  to save setting and move to next step.



Setting °C or °F

Setting#2: Set Clock

Press  or  to adjust Day → Hour → Minute.

Press  to save setting and move to next step.




Setting Clock

Setting#3: Set Temperature Offset:

The Offset value that you set will be added or subtracted from the ambient temperature reading shown on the display. This can be useful to match other temperature reading devices in the space.

Press  or  to adjust the Temperature Offset. (Range -4°F to +4°F)

Press  to save setting and move to next step. (Default 0°F)




Setting Temperature Offset

Setting#4: Set Brightness:

Press  or  to select the screen's contrast level from 1(Dimmiest) to 7 (Brightest).

Press  to save setting and exit initial setup. (Default 5)



Setting Brightness

INITIAL SETUP OF ECO PRO CONTROLLER - Cont.

Setting#5: System OFF or Freeze Protection OFF:

This option sets the preferred setting when the  button is pressed.

Press  or  to select between System OFF or Freeze Protection OFF


Press  to save setting and move to next step.

System Off = Disables the relay output and heater will never turn on under any scenario.


When activated **OFF** is shown on display.

Freeze Protection Off = Heater will turn on if the ambient room temperature drops below 40F.

When activated **OFF ** is shown on display.



System Off



Freeze Protection Off

Setting#6: WINDOW OPEN SETBACK Temperature (Optional Window/Door Sensor Accessory Required)

Sets the preferred setback temperature if an optional Window/Door sensor is connected to system.

Press  or  to select between 40°F (default), 45°F, 50°F, or 55°F.

Press  to save setting and move to next step.




Window Open Setback

Setting#7: PIR UNOCCUPIED SETBACK Temperature (Optional PIR Occupancy Sensor Accessory Required)

Sets the preferred setback temperature if an optional PIR Occupancy Sensor is connected to system.

Press  or  to select between 45°F, 55°F, 60°F (default), or 65°F.

Press  to save setting and exit initial setup.



PIR Unoccupied Setback

Setting#8: MULTIPLE HEATERS INSTALLATION SCENARIO (SAME ROOM OR DIFFERENT ROOMS)

Since ECO PRO Controller can be paired to multiple heaters, the status of each heater will be different under these two scenarios.

This option sets the control logic depending if multiple heaters are installed in a single room or different rooms.

Press  or  to select between 1 = Same Room (Default) or 0 = Different Rooms.

Press  to save setting and exit initial setup.

Note: At any time during the setup process you can Press and Hold the  button for several seconds to exit the initial setup early.

OPERATION OF ECO PRO CONTROLLER

PRESET SCENE TEMPERATURES:

ECO PRO Controller has 3 preset scene temperatures that you can quickly select to temporarily override the heating schedule, when your daily routine unexpectedly changes. Their default settings are shown in the following table:

Scene	Icon	Default Temp Settings
Home		70°F
Away		55°F
Sleep		60°F

HOW TO USE A PRESET SCENE:

Short Press the Preset Scene Temperature Icon  and it will start flashing. With each addition press it will switch between the 3 preset scenes.

Once the Scene you desire is shown, Press  to save Preset Scene.

That preset temperature becomes the current setpoint until the next Heat Schedule period starts , when the heater returns to the programmed heating schedule.



MODIFYING A PRESET SCENE TEMPERATURE:

Short Press the Preset Scene Temperature Icon  and it will start flashing. With each addition press it will switch between the 3 preset scenes.

Once the Scene you desire to modify is shown, Press  or  to adjust the temperature setpoint for that scene until the new desired setpoint temperature is shown.

Press  to save the new setpoint for the Preset Scene.

Note: This becomes the new setpoint, not only for the Preset Scene but also throughout your heating schedule where that scene is used.

PROGRAMMING THE HEATING SCHEDULE

DEFAULT HEATING SCHEDULE:

The ECO Pro Controller uses the PRESET SCENE TEMPERATURES setpoints (as described on the previous page) as the temperature setpoints for the time period in your heating schedule. The default heating schedule is shown in the following table. We recommend using the default schedule since it was designed to help reduce your heating expenses.

The schedule consists of 4 periods per day, which represents a typical work day.

The HOME  preset temperature is automatically used in Periods 1 and 3.

The AWAY  preset temperature is automatically used in Period 2.

The SLEEP  preset temperature is automatically used in Period 4.

You can have a different schedule for every day; i.e., each period can start at a different time every day.

Period	Icon	Scene	Mon	Tue	Wed	Thr	Fri	Sat	Sun
1		Home	6:00 AM						
2		Leave	8:00 AM						
3		Home	6:00 PM						
4		Sleep	10:00 PM						

The PRO Controller has been factory programmed with the above schedule.

HOW TO MODIFY THE HEATING SCHEDULE:

Step 1: Press  to start the process.

Mon begins to flash. Press  or  to select the Day of the Week you would like to modify.

Step 2: Press  again to move to the next step and select the Time Period you would like to modify.



Period 1 icon  begins to flash. If changing Period 1, Press  again to move to next step. Or Press  or  to change

to the Time Period you would like to modify such as Period 2  or Period 3  or Period 4 .

PROGRAMMING THE HEATING SCHEDULE

HOW TO MODIFY THE HEATING SCHEDULE - Continued:

Step 3: Press  again, Hour begins to flash. Press  or  to modify the Hour period starts.

Step 4: Press  again, Minutes begin to flash. Press  or  to modify Minutes period starts.

Step 5: Press  again to select the next period of the selected day to modify that period program according to the steps above.



After modifying the heat schedule as needed, Press  to save setting or wait for 15 seconds and the setting will be saved automatically.

COPY & PASTE A DAY'S SCHEDULE - Save Time Programming!

If you would like to copy the schedule for a specific day and add it to other days of the week, follow these steps and save time!



Step #1 After changing the schedule for a specific day (example Mon), Press  to save the day's schedule.

Step #2 Press the  icon to copy the selected day's schedule (example Mon). The remaining Days of the Week will appear on the screen.

Step #3 Press each day of the week that you want to paste Monday's schedule to. (For example: Tues, Wed, Thr, Fri).

As you press each day, a line will appear under the days you have selected.

Step #4 Press  to confirm the pasted schedule.

HEATING SCHEDULE OVERRIDE / ADJUSTING THE TEMPERATURE - (Temporary)

To adjust the desired temperature up or down, touch  and  on the thermostat home screen.

Note: Adjusting the temperature will temporarily override the current set point until the next schedule period unless you want to use one of the schedule overrides below.

GENERAL OPERATION

ECO PRO CONTROLLER OPERATING MODES

SYSTEM MODES:

PRO Controller has 3 system modes (Schedule, Override, Permanent Hold) that indicate if the state of the system. The current mode is displayed to the right of the Set To temperature on the home screen. The **set duration** of the current mode is displayed to the right of that, showing the time the system mode is active until. This makes it easy to identify when the next system change will occur.

- Schedule:** System is running based on the programmed heating schedule.
- Override:** System is running based on a manually set override for a limited amount of time.
- Permanent Hold:** System is running on a manually set override that will be permanently held until manually turned off.



OPERATION MODES:

PRO Controller has 4 operation modes (Heat, Timer, Hold, Fan Only). The current mode is displayed on the left, under the Date and Time on the home screen. The **set duration** of the current mode is displayed at the bottom right of the Set To temperature, showing the time it is active until.

To cycle through the available operation modes, touch **Mode**  on the thermostat home screen and select the appropriate mode and settings.

- Heat:** This is the default operation mode based on the heating schedule you have programmed.
- Timer:** This is a **temporary** system override based on the current system settings, that will expire after on a length of time you set.
- Hold:** This is a **permanent** system override that holds the current system settings permanently, until manually canceled.
- Fan Only:** This is a operating mode to run the fan only, typically used in the summer for cooling.

CHANGING THE OPERATION MODES:



Timer Mode: Press  once to enter into Timer Mode.

The timer Hour begins to flash. Press  or  to adjust the Hour for when the timer expires.

Press  and Minutes begin to flash. Press  or  to adjust.

Press  to save. Pro Controller will run based on current settings for that set period of time.

To cancel, press  three times get to Heat mode. Press  to save the mode.

Hold Mode: Press  two times to enter into Hold Mode.

Press  to save the mode.

Pro Controller will permanently hold the current temperature until manually canceled.



To cancel, press  two times get to Heat mode. Press  to save the mode.



GENERAL OPERATION

CHANGING THE OPERATION MODES - Continued:

Fan Only Mode: Press  three times to enter into Fan Only Mode.

Press  to save the mode.

When fan mode is selected there is no heat output. Fan turns on when room temperature is higher than the set temperature. When room temperature drops to the set temperature, fan turns off.

Note: The system functions as a cooling thermostat.



Fan Only Mode

To cancel, press  one time get to Heat mode. Press  to save the mode.

Heat Mode: Press  four times to return to Heat Mode. System functions based on Programmed Heat Schedule again.

Press  to save the mode.

SYSTEM OFF/STANDBY FUNCTION:

Press  button to enter or exit Standby Mode.

System will enter "System Off" or "Freeze Protection Off", depending on what default was set during INITIAL SETUP



System Off

(Heat Stays OFF Regardless of Room Temp)



Freeze Protection Off

MULTIPLE HEATERS PAIRED TO CONTROLLER - SYSTEM STATUS CHECK:

When multiple heaters are paired to a single ECO PRO Controller, if the heaters are installed in different rooms the status of each heater will be different based on the ambient temperature in each room. Follow the below steps to check the status of each heater:

Long press  for 5s to enter the check mode. The middle number represents different heaters, press  or  to check the status of each heater and the mode of it. Press  to exit the check mode.

GENERAL OPERATION

MAX TEMPERATURE LIMIT SETTING:

This setting allows the user to set a limit on the highest temperature setting allowed on the thermostat. It can be used in high traffic areas and can help prevent energy waste.



Press **Power** button to enter OFF mode



Press and hold **Calendar** and **Checkmark** button simultaneously for 5 seconds to enter Max Temperature setting mode



Press **Up** or **Down** to adjust the max temperature (40~95 °F)



Press **Checkmark** to confirm the setting or wait for 15 seconds and the setting will be saved automatically.



DISPLAY LOCK MODE:

Display Lock is designed for high traffic areas and deactivates the heater display buttons to prevent unwanted temperature adjustments. However settings can still be adjusted through the remote control.



Press and hold **Down** and **Power** button simultaneously for 5 seconds to enter Display Lock Mode.

All buttons on the Heater Display and ECO Pro Controller will be disabled until unlocked.



To Unlock: Press and hold **Down** and **Power** button for 5 seconds to exit Display Lock Mode.

Note: While in Display Lock Mode, the heater operates at the last known settings.

LOW BATTERY INDICATOR



When running on battery power, when the batteries are low on power the display shows **Battery icon**.

Replace batteries or plug into wall power.



FACTORY RESET UNIT



Press and hold **Up** and **Power** button simultaneously for 10 seconds.

All lights on the display will flash to confirm reset was completed and then the unit returns to its factory default settings & program.

DISPLAY WAKEUP (Wall Adaptor Connected)

The controller has a proximity sensor, so as you approach the controller the display will turn on automatically (detection range is 5 feet). When there is no activity for 30 seconds, the display will turn off automatically.



If the display does not turn on when you approach the controller, you can also press the **Checkmark** icon on the display to wake it up.

DISPLAY WAKEUP (Battery Powered)

When powered with batteries only, the display will automatically turn off after 15 seconds to save battery life.



Press the **Checkmark** icon on the display to wake it up.

Important Note: To conserve battery life the PRO Controller perform a handshake with the heater every 3 minutes. Users may experience up to a 3-minute delay.

Recommendation: For instant communication, a standard USB-C cable and power adapter are recommended to provide constant power.

CREATE A HEATING ZONE - Connect Multiple Heaters

Control Temperatures and Save Energy with Zoned Heating Systems

A zoned heating system allows homeowners to control the temperature of each room or zone individually, thereby maximizing comfort and minimizing energy costs. A zoned system can be adjusted for numerous factors, including room usage, personal preferences, and environmental conditions. Zoned systems help homeowners use their heating systems more effectively by distributing heat where and when it is needed.

A single ECO Pro Controller can be paired to multiple heaters, creating a Heating Zone that is controlled by a single heating schedule. All heaters in this zone will be synchronized to the heating schedule of the ECO Pro Controller.

Creating a Heating Zone

Step 1: Pair Multiple Heaters To A Single ECO PRO Controller

Follow the **Pairing and Usage** setup instructions on page 7 of this manual to pair each heater in the required heating zone to a single ECO PRO Controller. After pairing the first heater, repeat steps to pair each additional heater.

Step 2: Program The Desired Heating Schedule

Follow the **Program The Heating Schedule** instructions on page 14 to create a heating schedule for the ECO PRO Controller.

Step 3: Operation

All heaters within this heating zone are now synchronized and will operate off the programmed heating schedule. Any changes made to the ECO PRO Controller will effect all heaters in this zone. The ambient room temperature will be detected at the location of the ECO PRO Controller, so proper placement of the ECO PRO Controller is important. Locate the ECO PRO Controller in the coldest spot in the heating zone to eliminate any cold areas within the zone.

DIAGRAM OF AN EXAMPLE HEATING ZONE

